
Hanging the Projector Assembly onto the Projector Plate





QG-KIT-VA-3IN-W

INSTALLATION MANUAL

PROJECTOR MOUNTING KIT



Scan the QR Code™ below for more info about this product:





CAUTION!

Do not exceed the maximum rated weight specified. Otherwise, serious injury or property damage may occur.



■ Version: November 2017

Tighten the screws using Allen Key (H)

as shown on the right.

NOTE Please read the entire installation manual before you start installation and assembly.

WARNING

- Do not begin to install your QualGear product until you have read and understood all the instructions and warnings contained in this installation manual. If you have any questions regarding the instructions, for US customers, please contact QualGear customer support via email at support@qualgear.com. For all international customers, please contact your local distributor.
- This product requires installation by someone who has experience with basic building construction and fully understands these instructions.
- This product was designed to be installed and operated exactly as specified in this manual. Improper installation of this product may cause damage or serious injury. QualGear is not liable for the improper use or installation of its products.
- Make sure that the supporting surface safely supports the combined load of the equipment and all attached hardware and components.

- Always use an assistant or mechanical lifting equipment to lift and position the equipment safely.
- Tighten screws firmly, but do not over tighten. Over tightening can damage the items, greatly reducing their holding power.
- ALL QUALGEAR products are intended for indoor use only and any outdoor use voids the limited warranty. For warranty information, please visit:

http://www.gualgear.com/warrantv.php

- Never exceed the maximum rated weight specified in this manual.
- All hardware must be used at the designated points in the installation instructions to prevent property damage and personal injury.
- This product was designed to be compatible with all standard 1.5" NPT pipes.

IMPORTANT: Installers must verify that the supporting surface safely supports the combined weight of the equipment and all attached hardware and components.


Maintenance

Please check that the ceiling projector mount is secure and safe to use at regular intervals. If you have any questions regarding any of the instructions or warnings, please contact your local distributor (OR) contact QualGear technical support via email at support@gualgear.com.

Parts Checklist




IMPORTANT: Before starting the installation, please check to see that product package includes all parts as shown If any parts are missing or damaged, contact your local distributor or support@qualgear.com for replacement parts and do not start assembly and installation until you receive all the parts.




QualGear QG-PRO-PM-VCA-B or





Hardware Package




Mounting to a Vaulted Wooden Joist or Wooden Stud Ceiling









For concrete ceiling mounting, follow step 1b. NOTE




Using an edge-to-edge stud finder, find the edges of the stud.



Using a straight edge, mark the centerline of the stud.




Using wall marking template (B), mark on the center of the stud the locations of where you want to mount the ceiling adapter.





SKIP TO STEP 2



Using a power drill and a 5/32" wood drill bit, drill holes of 5/32" (4mm) diameter, and 2.5" (65mm) depth at the marked locations.

Mounting to a Vaulted Concrete Ceiling












Make sure that the drilled holes are free of dust for proper installation of anchors.




Using wall marking template (B), mark on the concrete the locations of where you want to mount the ceiling adapter.

3


Drill Diameter Ø 10mm (Ø 3/8")

Using a power drill and a 3/8" masonry drill bit, drill mounting holes of 3/8" (10mm) diameter and 1.8" (45mm) depth at the marked locations in the previous step.




Insert the metal expansion anchors (G) and hammer them into the drilled holes. Make sure to leave a portion of the anchors outside of the concrete. Then, take off the washers and the nuts on the anchors by using a socket wrench.

(2) Installing the Vaulted Ceiling Adapter to the Ceiling




3 Joining the Pipe to the Ceiling Adapter

IMPORTANT! Do not loosen screws all the way when making adjustments, this may disconnect the parts and may cause injury or property damage.



4 Disconnecting the Projector Plate from the Projector Mount

Slide the projector plate out from the projector assembly as shown on the right to disconnect the projector plate from the projector mount.



4 Connecting the Pipe to the Projector Plate

twist the male threaded end of the pipe into the female thread on the projector plate. 3-Inch NPT Pipe (D) Front **Projector Plate** Set Screws (L) Allen Key Using Allen Key (I), insert and tighten set screws (L) to secure the position.


To connect the 3-Inch NPT pipe (D) to the projector plate,

WARNING

- Installers are responsible for providing hardware for other types of mounting situations.
- Installers must verify that the supporting surface safely supports the combined weight of the equipment and all attached hardware and components.

7

Allen Key (H)




Depending on your projector, adjust the extension brackets on the projector mount (A) accordingly by using Allen Key (H).

If your projector model has three mounting holes only, please remove the fourth extension bracket using Allen Key (H).

The length and height of the extension brackets can be changed by sliding in and out, or up and down.

(6) Attaching the Projector Mount to the Projector



9